2 HDMI to DVB-T Encoder Modulator

(MPEG-2 HD/MPEG-4 HD Encoding + DVB-T Modulating)

SW Version: 1.07

HW version: 0.6

Web NMS version: 1.03

Date: 27th NOV, 2012

About This Manual

Intended Audience

This user manual has been written to help people who have to use, to integrate and to install the product. Some chapters require some prerequisite knowledge in electronics and especially in broadcast technologies and standards.

Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner.

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. DEXIN shall have no liability for any error or damage of any kind resulting from the use of this document.

Copy Warning

This document includes some confidential information. Its usage is limited to the owners of the product that it is relevant to. It cannot be copied, modified, or translated in another language without prior written authorization from DEXIN.

Directory

CHAPTER 1 INTRODUCTION 1

1.1 PRODUCT OVERVIEW 1

1.2 KEY FEATURES 1

1.3 SPECIFICATIONS 2

1.4 PRINCIPLE CHART 3

1.5 TYPICAL APPLICATION OF DUAL CARRIER OUTPUTS 4

1.6 APPEARANCE AND DESCRIPTION 4

CHAPTER 2 INSTALLATION GUIDE 6

2.1 GENERAL PRECAUTIONS 6

2.2 POWER PRECAUTIONS 6

2.3 DEVICE'S INSTALLATION FLOW CHART ILLUSTRATED AS FOLLOWING 6

2.4 ENVIRONMENT REQUIREMENT 6

2.5 GROUNDING REQUIREMENT 7

CHAPTER 3 OPERATION 8

3.1 LCD MENUS 8

3.2 INITIAL STATUS 10

3.3 GENERAL SETTINGS FOR MAIN MENU 10

CHAPTER 4 WEB NMS OPERATION 18

4.1 LOGIN 18

4.2 OPERATION 19

CHAPTER 5 TROUBLESHOOTING 30

CHAPTER 6 APPLICATION 31

CHAPTER 7 PACKING LIST 33

Chapter 1 Introduction

1.1 Product Overview

MOD-002 series products are one branch of DEXIN's knock-out all-in-one devices which integrate tuning (DVB-S/S2, ISDB-T) or encoding (MPEG-2, MPEG-4/AVC H.264) and modulation (DVB-C, DVB-T/T2, ISDB-T, or ATSC) to convert V/A signals into RF output. This manual is to introduce our new breakthrough work—a 1U rack model which integrates **MPEG-2 HD**/MPEG-4 HD (H.264) video encoding and DVB-T modulation to convert HD A/V signals to DVB-T RF out in the frequency range of 30~960MHz.

It adopts inner drawer-type structural design which greatly facilitates the change of encoding modules (HDMI/CVBS/SDI/YPbPr/…) as needed. To meet customers' various requirements, MOD-002 is also equipped with 1 ASI input, and output with 2 ASI ports and 1 UDP IP port.

The signals source could be from satellite receivers, closed-circuit television cameras, Blue-ray players, and antenna etc. Its output signals are to be received by TVs, STB and etc with corresponding standard.

With its various inputs available, our MOD-002 series products are wildly used in public places such as metro, market hall, theatre, hotels, resorts, and etc for advertising, monitoring, training and educating in company, schools, campuses, hospital… It's a good choice to offer HD channels and more.

1.2 Key Features

- Up to 1920*1080@50I/60I supported (MPEG2 HD) ;
  Up to 1920*1080@50P/60P supported (MPEG4 HD)/ (H.264)
- MPEG-2 HD/MPEG-4 HD (H.264) video encoding
- MPEG1 Layer II (MPEG2-AAC, MPEG4-AAC available) audio encoding
- 2* HDMI in (2 for backup), 1*ASI in

■ Single or dual (2 carriers combined output) RF DVB-T out available, double output bandwidth available

■ Video encoding bit-rate: 1-19.5Mbps

■ LCN support (Logical Channel Number)

■ Excellent modulation quality MER≥42dB

■ RF Frequency range 30Mhz~960Mhz

■ LCD display, Remote control and firmware

■ Updates via web

■ Lowest cost per channel --- Breakthrough price

1.3 Specifications

Encoding Section

Video

Encoding	MPEG2 HD/MPEG4 HD
Input	HDMI*2 (2 for backup)
Resolution	1920*1080_60P, 1920*1080_50P, (-for MPEG4/H.264) 1920*1080_60i, 1920*1080_50i, 1280*720_60p, 1280*720_50P

Audio

encoding	MPEG1 Layer II, (MPEG2-AAC, MPEG4-AAC available)
Sample rate	48KHz
Bit rate	64kbps, 96kbps,128kbps, 192kbps, 256kbps, 320kbps

DVB-T Modulator Section

Standard	EN300744
FFT mode	2K, 8K
Bandwidth	6M, 7M, 8M
Constellation	QPSK, 16QAM, 64QAM
Guard Interval	1/4, 1/8, 1/16, 1/32
FEC	1/2, 2/3, 3/4, 5/6, 7/8
MER	≥42dB
RF frequency	30~960MHz, 1KHz step
RF out	Option 1: 1* RF COFDM DVB-T out Option 2: 2*RF COFDM DVB-T out (2 carriers combined output); Double output bandwidth
RF output level	-30~ -10dbm (81~97 dbμV), 0.1db step

System

Local interface	LCD + control buttons
Remote management	Web NMS
output	ASI out (BNC type); IP out (RJ45, 100M)
NMS interface	RJ45, 100M
Language	English

General

Power supply	AC 100V~240V
Dimensions	482*300*44mm
Weight	4.5 kgs
Operation temperature	0~45℃

1.4 Principle Chart

For Single Carrier Output



For Dual Carrier Outputs



1.5 Typical Application of Dual Carrier Outputs

To guarantee the picture quality of 1920x1080I resolution HD program, the video bit-rate often comes more than 10 Mbps, even reaches up to 18Mbps or more. However, the maximum possible bit-rate output for single DVB-T carrier is only around 30Mbps.

18Mbps x2 =36Mbps >30Mbps.

It means the single DVB-T carrier simply can't carry 2 channels 1080i HD programs.

That's why we design 2* DVB-T carriers modulation board which double the maximum possible bit-rate bandwidth up to 60Mbps, which rightly makes it possible to carry 2 channels HD program output simultaneously.



1.6 Appearance and Description

Front Panel Illustration



① **LCD window: LCD display**
② **NMS & DATA ports**
③ **Power and Alarm Indicators**
④ **Lock Indicators**
⑤ **Up and down, left and right button**
⑥ **Enter button: for confirm**
⑦ **Menu button: for back step**
⑧ **Lock button: press to lock set**

Rear Panel Illustration



① HDMI Module 1: HDMI input port 1&2 (one for standby)
② HDMI Module 2: HDMI input port 3&4 (one for standby)
③ RF in port
④ RF out port
⑤ ASI input port
⑥ ASI output ports
⑦ Switch
⑧ Power supply slot
⑨ Grounding

Chapter 2 Installation Guide

This section is to explain the cautions the users must know in some case that possible injure may bring to users when it's used or installed. For this reason, please read all details here and make in mind before installing or using the product.

2.1 General Precautions

- ✓ Must be operated and maintained free of dust or dirty.
- ✓ The cover should be securely fastened, do not open the cover of the products when the power is on.
- ✓ After use, securely stow away all loose cables, external antenna, and others.

2.2 Power precautions

- ✓ When you connect the power source, make sure if it may cause overload.
- ✓ Avoid operating on a wet floor in the open. Make sure the extension cable is in good condition
- ✓ Make sure the power switch is off before you start to install the device

2.3 Device's Installation Flow Chart Illustrated as following



2.4 Environment Requirement

Item	Requirement
Machine Hall	When user installs machine frame array in one machine hall,

Space	the distance between 2 rows of machine frames should be 1.2~1.5m and the distance against wall should be no less than 0.8m.
Machine Hall Floor	Electric Isolation, Dust Free Volume resistivity of ground anti-static material: $1X10^{7}$~$1X10^{10}\Omega$，Grounding current limiting resistance: 1MΩ (Floor bearing should be greater than 450Kg/㎡)
Environment Temperature	5~40℃(sustainable)，0~45℃(short time)， installing air-conditioning is recommended
Relative Humidity	20%~80% sustainable 10%~90% short time
Pressure	86~105KPa
Door & Window	Installing rubber strip for sealing door-gaps and dual level glasses for window
Wall	It can be covered with wallpaper, or brightness less paint.
Fire Protection	Fire alarm system and extinguisher
Power	Requiring device power, air-conditioning power and lighting power are independent to each other. Device power requires AC 110V±10%, 50/60Hz or AC 220V±10%, 50/60Hz. Please carefully check before running.

2.5 Grounding Requirement

- ✓ All function modules' good grounding is the basis of reliability and stability of devices. Also, they are the most important guarantee of lightning arresting and interference rejection. Therefore, the system must follow this rule.
- ✓ Grounding conductor must adopt copper conductor in order to reduce high frequency impedance, and the grounding wire must be as thick and short as possible.
- ✓ Users should make sure the 2 ends of grounding wire well electric conducted and be antirust.
- ✓ It is prohibited to use any other device as part of grounding electric circuit
- ✓ The area of the conduction between grounding wire and device's frame should be no less than 25 mm^2.

Chapter 3 Operation

3.1 LCD Menus

An overview of the LCD menus:





Submenus 4.1&4.2 are set for dual-carrier-output Encoder Modulator. For single-carrier-output, "4 IP Out Setting" goes directly to 4.1.1-4.1.6









3.2 Initial Status

Switch on the device and after a few seconds' initialization, it presents start-up pictures as below:



- DVB-T: indicate the modulation standard of this device
- XXX.XX MHz indicates the current output frequency (range: 30~960MHz)
- X.XX Mbps indicate the encoding bit rate of each channel respectively.

3.3 General Settings for Main Menu

Press "Lock" key on the front panel to enter the main menu. The LCD will display the following pages where user can configure the parameters for the device:



User can press UP/DOWN buttons to specify menu item, and then press ENTER to enter the submenus as below:

1) Alarm Status

The alarm indicator will turn on if there is no A/V signals inputting or outputting bit rate overflows. User then can enter this menu to check the error type.

2) Encode Setting

Under this submenu, the LCD will show "2.1 Input 1", "2.2 Input 2" and "2.3 ASI".

Under submenus 2.1 or 2.2, user could set the video encoding format and bit rate, and set audio encoding bit rate and also read the audio encoding format of the program from the HDMI input.



"Video Format": the HDMI MPEG2 HD encoding module supports both MPEG2 and H.264 formats. Move the triangle mark with LEFT/RIGHT keys to specify the intended format and press ENTER to confirm.

"Video Bit Rate": Move the underline with LEFT/RIGHT keys and modify the value of frequency with UP/DOWN keys, and press ENTER key to save the settings.

"Audio Format": the encoding module supports MPEG2 audio format. This is a read-only interface for checking.

"Select Program" is to select programs from the RF IN to output. Move the triangle mark to specify the program and press ENTER to confirm.

Under submenu 2.3, user could parse the inputting programs and select the programs to output.



"Parse Program" is for checking the quantity of input programs from the corresponding Tuner input.

"Select Program" is for selecting programs from the ASI IN to output. Move the triangle mark to specify the program and press RIGHT/LEFT keys to shift the mark between "√" and "X". ("√": to output the corresponding program; "X": not to output the corresponding program)

3) Modulator Setting

When entering "Modulator Setting" submenu, user can find below different parameters can be set and the LCD window would show as below:

NOTE: As for "3 Modulator Setting", submenus 3.1 and 3.9 are especial for dual-carrier-output encoder modulator since our modulating module currently has two types: single-carrier-output and dual-carrier-output.

For single-carrier-output encoder modulator, submenus under "3 Modulator Setting" are without 3.1 and 3.9.

- **Output Select**

  If the encoder & modulator is with dual-carrier output: Output A and Output B. This interface is for selecting the one of the outputs to configure the following items (3.2-3.8).

- **Bandwidth**

  There are three possible options provided for selecting bandwidth: 6M, 7M, and 8M. When the display shows them, user just need swift LEFT and RIGHT key to choose and repressing ENTER to confirm.



- **Constellation**

  There are three different constellations QPSK, 16QAM and 64QAM shown on the LCD window. When entering Constellation, user can apply the same setting method as mentioned above to select and confirm one mode.



- **Transmission Mode**

  When user enters Transmission Mode, the LCD would show the current working mode. User can move LEFT/RIGHT keys to select and press ENTER key to confirm. 2K and 8K are the options:



2K: When the device works as current mode, the number of current carrier is 2048

8K: When the device works as current mode, the number of current carrier is 8192

- **Guard Interval**

In communications, guard intervals are used to ensure that distant transmissions do not interfere with each other. These transmissions may belong to different users (as in TDMA) or same user (as in OFDM). The purpose of the guard interval is to introduce immunity to propagation delays, echoes and reflections, to which digital data is normally very sensitive. There are four possible options provided to be selected. They are 1/4, 1/8, 1/16, 1/32. User can shift the LEFT/RIGHT keys to select and press ENTER to confirm.



- **Code Rate**

The code rate includes 1/2, 2/3, 3/4, 5/6, and 7/8. After entering this submenu, the LCD display would show them, users just need press LEFT and RIGHT buttons to choose and press ENTER button to confirm.



- **RF Frequency**

The RF output frequency range is from 30 to 960MHz with 1K stepping. After entering the RF frequency setting submenu, users the can press LEFT, RIGHT, UP, and DOWN buttons to adjust the frequency and confirm by press ENTER button.



- **RF Out Level**

The RF attenuation range is -30~-10dbm (81~97dbμV) with 0.1db step. After entering

this setting submenu, user can shift UP/DOWN/LEFT/RIGHT key to set the output level and press ENTER to confirm.

- **ASI Output**

If the encoder & modulator is with dual-carrier output: Output A and Output B.

Output A: the ASI output programs are same as carrier output A.

Output B: the ASI output programs are same as carrier output B.

4) IP Output Setting

If the encoder & modulator in use is with two dual-carrier output (Output A and Output B), 4.1 and 4.2 are for the settings of the two carrier output respectively. If it is a single-carrier output encoder & modulator, the submenus go directly to 4.1.1-4.1.6.



User can enter 4.1.1 to decide whether to turn the IP port on or off, and enter to the rest menu items to set the corresponding parameters.

5) Network setting

After enter Network Setting, there are three submenus shows as the following LCD displays.



User can press “UP/DOWN” to choose this item and “ENTER” & “LEFT/RIGHT” to set the parameters.



NOTE: The MAC address is according to the factory setting, and it is unique.

6) Saving Configuration

Users can enter Saving Configuration submenu for saving settings. Choose yes and press ENTER to confirm.



7) Loading Configuration

At this menu, user can press UP/DWON key to select and repress ENTER to confirm. User can restore the device into the last saved configuration by choosing “7.1” and restore the device into factory configuration by choosing “7.2” the display will show as below:



8) Version

User can check the software version and hardware version of this equipment under this submenu.

Chapter 4 WEB NMS Operation

User not only can use front buttons to set configuration, but also can control and set the configuration in computer by connecting the device to web NMS Port. User should ensure that the computer's IP address is different from the MOD-002's IP address; otherwise, it would cause IP conflict.

4.1 login

The default IP address of this device is 192.168.0.136. (We can modify the IP through the front panel.)

Connect the PC (Personal Computer) and the device with net cable, and use ping command to confirm they are on the same network segment.

I.G. the PC IP address is 192.168.99.252, we then change the device IP to 192.168.99.xxx (xxx can be 0 to 255 except 252 to avoid IP conflict).

Use web browser to connect the device with PC by inputting the Encoder & Modulator's IP address in the browser's address bar and press Enter.

It will display the Login interface as Figure-1. Input the Username and Password (Both the default Username and Password are "admin".) and then click "LOGIN" to start the device setting.



Figure-1

4.2 Operation

When we confirm the login, it displays the WELCOME interface as Figure-2.



Figure-2

Dual-carrier-output VS Single-carrier-output


Output
Output A Output B
Maxout Bitrate: 31.670 Mbps 31.670 Mbps
Current Bitrate: 29.683 Mbps 14.911 Mbps
TS Overflow:
RF Frequency: 850.000 MHz 858.000 MHz
RF Outlevel: -10.0 dBm
"A" & "B" respectively represent carrier A and carrier B.
Output
Maxout Bitrate: 31.668 Mbps
Current Out Bitrate: 14.784 Mbps
TS Overflow:
RF Frequency: 750.000 MHz
RF Outlevel: -10.0 dBm
This section is captured from the Web page of single-carrier-output

Input 1

From the menu on left side of the webpage, clicking "Input 1", it displays the information of the program from the 1st HDMI encoding module as Figure-3.



Figure-3

Dual-carrier-output VS Single-carrier-output



Carrier A: Click this box to enable or disable the program output through Carrier A.

Carrier B: Click this box to enable or disable the program output through Carrier B.



This section is captured from the Web page of single-carrier-output. It does not refer Carrier A or B.

Help For user to turn to refer detailed explanation of terms on this interface

Default Click this button to apply the default setting of Input 1

Apply Click this button to apply the modified parameters.

Input 2

Similarly, from the menu on left side of the webpage, clicking “Input 2”, it displays the information of the program from the 2ed HDMI encoding module.

ASI Input

Click “ASI Input”, it will display ASI input program information as Figure-4.



Figure-4

Output A B Select the carrier output channel for the multiplexed programs. **(Remarks: This section only exists and is applicable to dual-carrier-output device.)**

Passthrough If this item is selected, all the input programs will pass through without any elimination.

Multiplex Selecting this item to allow user select programs as required to output.

Refresh Input Click “Refresh Input” to refresh the input program list.

Refresh Output Click “Refresh Output” to refresh the output program list.

Select Program When user checks one input program with “√”, one can transfer the

checked program to the right box to output.

Here user can select the programs which we want to output or we can output all the programs.

Cancel Program Similarly, user can cancel the multiplexed programs from the right box.

All Input & All Output to select all the input/output programs with one-time clicking.

Parse timeout 200 seconds Time limitation to parse the input programs

PID Pass Click this button to trigger a dialog box as below, where to add the PIDs which need pass through.

In some occasions, there are some PIDs which won't belong to any program, such as EPG, NIT tables and so on which user just wants to pass them through the multiplexing module without changing anything. This is the main purpose of this function.



Click "Add" Add to add more boxes for filling the Input & Output PIDs, then click "Apply" to confirm.

NIT Table setting

Click "NIT" from the menu to trigger the screen as Figure-5. Then click "Add" from this screen to add the program descriptor in NIT Table.



Figure-5



Select the carrier output channel for the inserted NIT. **(Remarks:** This section only exists and is applicable to dual-carrier-output device.**)**

Click "Add" from this page, it will display the screen as Figure-6 where it requires to add Service ID and configure other parameters for the programs.



Figure-6



Here by clicking "Add", users can set the program LCN in its respective field. After setting all the data, users need to click on "Save"

to save the

setting. As Figure-7, click "Update NIT" Update NIT to update the NIT information.

TSID	ONID	Freq(MHz)	Bandwidth	Const	LCN
0x0001	0x0001	750.000	8 MHz	64 QAM	yes

Figure-7

IP Output

Click "IP Output" from the left menu, it will display the screen as Figure-8 where to set the multicast IP Output address for the device if needed and set the IP output for the programs.

After setting the parameters, click "Apply" to save the setting.


Web Management
Welcome
Parameter
Input 1
Input 2
ASI Input
NIT
IP Output
Modulator
Save/Restore
System
Reboot
Firmware
Network
Password
Backup/Load
IP Output Configuration
IP Output Enable: If not set, the following parameters will be no use, the IP Output will not work.
Service IP: The IP Output port address. The format is xxx.xxx.xxx.xxx(like as 192.168.2.137).
Output IP: The IP Output data receive address. The format is xxx.xxx.xxx.xxx(like as 224.2.2.2). After set the Output IP addrress, you must use the new address to receive IP Output data.
Subnet Mask: General is 255.255.255.0, it is must the same in a local area network.
Gateway: If the device is in different net segment, you must set the gateway.
Port: The UDP protocal port(like as 8001), you should use Output IP and new port to receive IP Output data(like as udp://224.2.2.2:8001).
IP Output Enable A:
IP Output Enable B:
Output IP A: 224.2.2.2
Output IP B: 224.2.2.2
Port A: 1234
Port B: 1235
Service IP: 192.168.2.137
Subnet Mask: 255.255.255.0
Gateway: 192.168.2.0
Default
Apply

Figure-8

Dual-carrier-output VS Single-carrier-output





Modulator Setting

Enter in "Modulator" and it will display the Modulator Configuration screen as Figure-9 where can set modulation parameters.

Bandwidth –Bandwidth selecting. (The default bandwidth is 8M)

Constellation –QAM type selecting. (The default constellation is 64QAM)

Transmission Mode –2K, 8K optional

Guard Interval/Code Rate/RF Frequency/RF Out level – the default configuration is as shown on Figure 9.

ASI Output– Carrier output channel selecting (**Output A:** The ASI output programs are same as carrier output A. **Output B:** The ASI output programs are same as carrier output B.)

After setting all the parameters, click "Apply" Apply to save the Modulator Configuration.



Figure-9

Save/Restore

Clicking "Save/Restore" from the menu, it will display the screen as Figure-10 where

can save the configuration permanently to the device. Click “Save Configuration”, for store the data permanently to the device.

By using “Restore Configuration” user can restore the latest saved configuration to the device.

By using “Factory Set” user can import the default factory configuration.



Figure-10

Restart the Device

Click “Reboot” from the menu, the screen will display as Figure-11. Here when clicking “Reboot” box, it will restart the device automatically.



Figure-11

Update the Device

Click “Firmware” from the menu it will display the screen as Figure-12. Here user can update the device by using the update file.

Click “Browse” to find the path of the device update file for this device then click “Update” to update the device.

After updating the device, user needs to restart the device by using Reboot option.



Figure-12

Network

When user clicks “Network”, it will display the screen as Figure-13. It displays the network information of the device. Here user can change the device network configuration as needed.


Web Management
Welcome
Parameter
Input 1
Input 2
ASI Input
NIT
IP Output
Modulator
Save/Restore
System
Reboot
Firmware
Network
Password
Backup/Load
Network
IP Address: The manege address,use this address to visit the manege web.The format is xxx.xxx.xxx.xxx(like as 192.168.0.1). After set the IP addrress,you must use the new address to visit the manege web.
Subnet Mask: General is 255.255.255.0,it is must the same in a local area network.
Gateway: If the device is in different net segment,you must set the gateway.
Web Manage Port: The default web manage port is 80,if you change it(like as 8001),you can visit the manege web only use IP address and port(liks as http://192.168.0.1:8001).This function will work after device reboot.
IP Address: 192.168.0.136
Subnet Mask: 255.255.255.0
Gateway: 192.168.0.1
Web Manage Port: 80
Apply

Figure-13

Change Password

When user clicks “Password”, it will display the password screen as Figure-14. Here user can change the Username and Password for login to the device.

After putting the current and new Username and Password, click Apply” to save the configuration.



Figure-14



➢ Keyboard and LCD Lock: If it is marked with “√”，the LCD and keyboard will be

locked to avoid unrelated users' modifying or view the device information and configurations. User can't operate the keyboard & LCD while only the device IP address can be noted in the LCD window.



Backup/Load

Click "Backup/Load" from the menu, it will display the screen as Figure-15.

Backup Configuration – To back up the device configuration file to a folder

Load Configuration – If user needs to load the old configuration to the device, click "Browse" and find the backup configuration file path. After selecting the file, click "Load File" to load the backup file to the device.



Figure-15

Chapter 5 Troubleshooting

DEXIN's ISO9001 quality assurance system has been approved by CQC organization. For guarantee the products' quality, reliability and stability. All DEXIN products have been passed the testing and inspection before ship out factory. The testing and inspection scheme already covers all the Optical, Electronic and Mechanical criteria which have been published by DEXIN. To prevent potential hazard, please strictly follow the operation conditions.

Prevention Measure

- Installing the device at the place in which environment temperature between 0 to 45 °C
- Making sure good ventilation for the heat-sink on the rear panel and other heat-sink bores if necessary
- Checking the input AC within the power supply working range and the connection is correct before switching on device
- Checking the RF output level varies within tolerant range if it is necessary
- Checking all signal cables have been properly connected
- Frequently switching on/off device is prohibited; the interval between every switching on/off must greater than 10 seconds.

Conditions need to unplug power cord

- Power cord or socket damaged.
- Any liquid flowed into device.
- Any stuff causes circuit short
- Device in damp environment
- Device was suffered from physical damage
- Longtime idle.
- After switching on and restoring to factory setting, device still cannot work properly.
- Maintenance needed

Chapter 6 Application

Application Examples

1). Residences and Private Homes Video content DVB-T/ISDB-T distribution



2) Outside Audio - Video contents ON - AIR DVB - T/ISDB-T distribution



3) Hotel Audio - Video contents DVB - T/ISDB-T distribution



4) Bar Audio - Video contents distribution



5) Cinema Audio - Video contents DVB - T/ISDB-T distribution



6) Company Audio - Video contents distribution



Chapter 7 Packing List

Encoder Modulator	1PC
User's Manual	1PC
HDMI Cables	2PCs
Power Cord	1PC

APPENDIX

Our encoder & modulator series are individual-module design, and the encoding modules include:

- ✓ MPEG2 SD super encoding with 2 CVBS in
- ✓ MPEG2 encoding with 1CVBS in
- ✓ MPEG4 AVC H.264 encoding with 1 or dual SDI in
- ✓ DVB-S2 tuner input
- ✓ YPbPr +HDMI +CVBS input
- ✓ MPEG4 AVC/H.264 encoding with One or dual HDMI input
- ✓ MPEG2 HD encoding with one HDMI input

Modulation modules include:

- ✓ ISDB-T RF out module
- ✓ DVB-C RF out module
- ✓ ATSC RF (single/dual/quad carriers) out module
- ✓ DVB-T RF (single carrier/dual carriers) out module